

Performables

A range of durable options to meet performance needs.

Indiana
FURNITURE



TECHNICAL INFORMATION

PATTERN	CONTENT	BACKING	TOPCOAT	ABRASION	LIGHT-FASTNESS	WIDTH	WEIGHT	ROLL SIZE	COLD CRACK	GRADE
Genero EcoSense	Vinyl	100% Polyester	Urethane Topcoat	100k	650 Hours	54 in.	24 oz.	30 yd.	-10 °F	2
Maglia EcoSense	Vinyl	Hi-Loft ² ™ 100% Polyester	PERMABLOK	100k	1000 Hours	54 in.	30 oz.	30 yd.	-10 °F	3
Silvertex NEO	Vinyl	Hi-Loft ² ™ 100% Polyester	PERMABLOK	100k	1000 Hours	54 in.	30 oz.	30 yd.	-10 °F	3
Whisper NEO	Vinyl	Hi-Loft ² ™ 100% Polyester	Napa	100k	1000 Hours	54 in.	27 oz.	30 yd.	-20 °F	2

FLAME RETARDANCY	GEN	MAG	STX	WHI
NFPA 260 - Cover Fabric - Class I	✓	✓	✓	✓
UFAC Fabric - Class I	✓	✓	✓	✓
CAL TB 117-2013	✓	✓	✓	✓

APPLICATIONS	GEN	MAG	STX	WHI
Healthcare	✓	✓	✓	✓
Hospitality	✓	✓	✓	✓
Restaurant	✓	✓	✓	✓
Hotel/Motel/Casino	✓	✓	✓	✓
Public Spaces	✓	✓	✓	✓
Office	✓	✓	✓	✓
Education	✓	✓	✓	✓
Residential Interior	✓	✓	✓	✓
Residential Exterior			✓	
Marine Interior	✓	✓	✓	✓
Marine Exterior			✓	
Auto/RV				

GENERO, MAGLIA & SILVERTEX CARE AND CLEANING GUIDE

STEP 1	Common stains: eye shadow, mascara, grease, black felt tip pen, crayon, chocolate, suntan lotion, and hair/body oils* Remove excess spill with a damp cloth. Use a 1:1 mix of Ivory® liquid soap and water. Rub gently with a soft clean cloth, rinse with clean water and dry.
STEP 2	Common stains: red lipstick Use a straight application of concentrated cleaners such as Formula 409® or Fantastik® spray cleaner. Rub gently with a soft clean cloth, rinse with clean water and dry.
STEP 3	Common stains: blood, urine, feces, and oil-based paint Use a 1:1 mix of ammonia and water or a 1:10 mix of bleach and water. Rub gently with a soft clean cloth, rinse with clean water and dry.
STEP 4	All other tough stains Use a cotton cloth saturated in a 1:1 mix of isopropyl alcohol and water. Rub gently in a circular motion 10 times. Pat dry and check the results. If the stain persists, use straight alcohol and rub the stain again using the circular motion. Rinse thoroughly with clean water and pat dry.

*Must be cleaned after each instance of exposure to hair and body oils.

WHISPER CARE AND CLEANING GUIDE

STEP 1	Light soiling Use a solution of 10% household liquid dish soap in warm water, applied with a soft damp cloth. Rub gently and rinse with a water-dampened cloth.
STEP 2	Heavy soiling Dampen a soft white cloth with a one-to-one (1:1) solution of Formula 409® and water or Fantastik® and water. Rub gently and rinse with a water-dampened cloth.
STEP 3	More difficult stains Dampen a soft white cloth with a solution of household bleach (10% bleach and 90% water). Rub gently and rinse with a water-dampened cloth to remove bleach concentration.

*Do not use with alcohol-based cleaning agents.

Indiana
FURNITURE

800-422-5727
indianafurniture.com

