


Joy Seating

User Instructions

Control Adjustments

Joy chairs are available in synchro-tilt control options, with or without a seat slider. The following graphics will help you determine which control has been installed on your chair.

Note: images are showing the bottom of the control. Thus, it will be inverted once installed on your chair.



A Seat Height Adjustment

To raise the seat height, stand up or raise your body so there is no pressure on the seat. Lift the paddle and raise the seat to the desired height.

To lower the seat height, sit in the chair to apply pressure on the seat. Lift the paddle and lower the seat to the desired height.

B Tilt-Lock Adjustment

While seated, push the paddle forward to unlock the back and allow tilt or recline. Push the paddle backward to lock into position.

C Tension Control

While seated, turn the knob forward to tighten the tension, turn the knob backward to loosen the tension.


D Seat Slider

While seated, lift the paddle and shift your body weight forward or backward to move the seat to the desired position.

Or, while standing and facing the chair, lift the paddle with one hand and move the seat to the desired position with the other.

Arm Adjustments

There are multiple arm options available on Joy seating. Some of the arm styles are fixed/static, while others offer height adjustability, width adjustability, and/or sliding/pivoting arm pads.



A Height Adjustment

To raise the arm height, push up the lever and raise the arm. To lower the arm height, push up the lever and lower the arm.

Repeat for both arms.

B Width Adjustment

To move the arm out from the seat, turn the knob backward to loosen, then move the arm to the desired position. Turn the knob forward to tighten and secure into position.

Repeat for both arms.

C Sliding/Pivoting Arm Pads

To slide the arm pad forward or backward, grasp the top of the pad and move to click in desired place. To pivot the arm pad, grasp the top of the pad and move left or right to click into place.

Repeat for both arms.

Lumbar Adjustment

Lumbar is available on all mesh back chairs. To adjust, grab the tabs on each side of the lumbar, at the bottom, and move up or down to desired position.

